

Installation, Safety and Maintenance Instructions

Dynamic Bollard



PACKAGE CONTENTS



Bollard

1 pc



Concrete Anchor Bolts

(14 × 135 mm)
4 pcs per base



Base Plate

1 pc



Elastomer

1 pc



REQUIRED TOOLS



Hammer drill with 14 mm concrete drill bit



Electric impact wrench with 22 mm socket



Vacuum cleaner for dust removal

Impact Control



sales@imp-control.com



imp-control.com



INSTALLATION INSTRUCTIONS

STEP 1 Positioning

Place the bollard in the desired installation location.

STEP 2 Marking the Drill Holes

Using the holes in the base plate as a guide, mark the drilling points on the concrete surface. This can be done using either a drill tip or a marker.

STEP 3 Drilling

Drill holes with a 14 mm diameter to a minimum depth of 135 mm.

STEP 4 Cleaning the Holes

Remove dust and debris from the drilled holes using a vacuum cleaner.

STEP 5 Positioning the Bollard Assembly

1. First place the elastomer on the floor.
2. Ensure that the elastomer logo is facing downward.
3. Place the bollard on top of the elastomer.
4. Place the base plate over the bollard and elastomer, aligning it with the drilled holes.

STEP 6 Fixing the Anchor Bolts

Insert the anchor bolts into the holes and tighten them partially.

STEP 7 Final Tightening

Tighten all anchor bolts evenly using the electric impact wrench until the base plate is firmly secured to the floor.





SAFETY INSTRUCTIONS



Ensure the concrete floor is structurally sound and suitable for anchoring before drilling.



Always wear appropriate personal protective equipment (PPE), including safety glasses, gloves, and hearing protection during drilling and installation.



Use only the recommended tools and anchor bolts for installation.



Improper installation may reduce the effectiveness of the protection bollard and could lead to equipment damage or personal injury.



MAINTENANCE / INSPECTION



After installation, verify that all anchor bolts are properly tightened.



Perform periodic visual inspections to ensure the bollard remains securely fixed to the floor.



Check the bollard for visible deformation, loosened anchors, or damage after any impact.



If significant damage or structural deformation is observed, the bollard should be replaced immediately.



Ensure that all fasteners remain tight and that the base plate remains flush with the floor surface.



TECHNICAL NOTES



Recommended drill hole diameter: Ø14 mm



Minimum drill depth: 135 mm



Anchor bolts must be tightened evenly to ensure proper load distribution on the base plate.



Installation is intended for concrete surfaces only, unless otherwise specified.



For optimal performance, ensure the base plate is fully supported by the floor surface and not installed on uneven or damaged concrete.

Impact Control